
## 56SW15 and MSW15

15A

240V

50Hz



To install fit pins 'A' and 'B' into apertures as shown and press down until the module is locked in place

## **Assembly Diagram**

08/04 659275