CRC Industries NZ, Auckland NZ

### I. Product Description

CRC Surface Sanitiser is a dual action cleaner and sanitiser suitable for almost all surfaces. This product contains added surfactants for boosted cleaning performance CRC Surface Sanitiser provides two complete actions in one product by both cleaning and disinfecting surfaces. It is effective against bacteria, fungi and viruses. Especially suitable for surfaces sensitive to alcohol (e.g. leather, PVC and acrylic glass).

#### II. Features & Benefits

- · Ready to use
- Dual action cleaning and sanitizing.
- Rapid contact time 30 seconds minimum
- · Suitable for surfaces sensitive to alcohol

### III. Application and Directions

CRC Surface Sanitiser is a ready-to-use solution. Apply liquid undiluted to objects and surfaces and allow to take effect. Ensure that surfaces are thoroughly wetted. If necessary, remove excess product with a dye-free disposable wipe. Ensure a minimum of 30 seconds contact time for effective sanitising action.

# IV. Typical Properties and Characteristics

Appearance	Clear light green liquid
Odour	Mild fragrance
Boiling Point	> 100°C
Solubility	Miscible in water
pH	7.5 – 8.0
Composition (g per 100g)	0.2 g Quaternary ammonium compounds, benzyl-C12-C16-alkyldimethyl, chlorides, 0.2g Didecyldimethylammonium chloride,
Flammability	Non-flammable

## V. Package Description

Part Number	Size
1572080	500ml
1752106	750ml
1752084	4 Litre
1752089	5 Litre



## VI. Special Precautions

Use biocides safely. Always read the label and product information before use.

For all of the related safety information please refer to the Safety Data Sheet which available at <a href="https://www.crc.co.nz">www.crc.co.nz</a>

Wearing gloves (e.g. of nitrile rubber) is recommended.

Keep container tightly closed. Protect from frost, heat and sunlight.

Store at room temperature in the original container. Only recycle completely emptied packaging. Do not exceed usage of more than 50ml per m2.

Avoid contact with the eyes. Store out of the reach of children.

Not for final disinfection of semicritical and critical medical devices.

Refer to Material Safety Data Sheet for more details.

TECHNICAL DATA SHEET Version 04/20

<u>PRODUCT WARRANTY</u>: CRC offers a conditional warranty of this product for the period of 2 years from the date of manufacture.

**DISCLAIMER:** All information on this data sheet is based on testing by CRC Industries NZ. All products should be tested for suitability on a particular application prior to actual use. CRC Industries makes no representations or warranties of any kind concerning this data.